




■Table of Components				
No.	Description	Qty	Material and Remark	
1	Base plate	1	SS400	
2	Bracket	1	SS400	
3	Connector Plate Mounting Board	1	SS400	
4	Collar	1	SS400	
(5)	Guide Pin	1	S45C □22	
6	Guide Holder (upper)	1	Bronze with Graphite (SO-2)	
7	Guide Holder (lower)	1	Bronze with Graphite (SO-2)	
8	Limit Switch	1	1LS2-J/WL-1A200 by Yamatake	
9	CAPCON (cable clamp)	1	0A-1 by Ohm Electric	
10	Nylon Connector Set	1	D-NLCS-1941-3P/R	
11)	Air Cylinder	1	by SMC (Φ40)	







Catalog No.	Travel S
	150
	200
APEHB (With Bracket)	250
	300
(Without Bracket)	350
	400
	500



Catalog No. S

APEHB 250
APEH 250



Catalog No.



Catalog No.

■For operation

- •When the bracket is used, the pusher can be folded for storage.
- •Since the guide pin is square shaped, it does not turn.
- •Type with or without bracket can be selected.
- •When the unit is assembled to the die, weld the bracket to the desired position of the base plate.

Refer to page 353 to 354 for the pusher spring head and the connector plate.