


Sheet Support Gauge

SHEET SUPPORT GAUGE









■For Operation

- ullet If weight of oxdot support plate is not sufficient for the blank weight, put some weights for use.
- •To turn the support plate, load of approx. 1.2 kg is required.
- Machine the upper die to prevent interference with the gauge unit and the support plate. (The allowance for clearance is about 10 mm.)