## **SKCA** [Overview]

## **Product Information**

- Mount face widths 52, 65, 100, 150, 200, 250, and 300 mm.
- •Working angles from 0° to 20° in 5° increments for 65, 100, and 150 mm.
- Mount face widths of 52, 200, 250, and 300 mm are available with an angle of 0°.
- •Gas Spring is available in 65, 100, 150, and 200 mm width and 0°.
- The Box-type holder provides high rigidity.



#### **■**Gas Spring Specifications

Mount face				Working For	ce [kN (tonf)]	
w	Н	Working Angle	Travel	Standard Working Force 1,000,000 strokes	Allowable Working Force 300,000 strokes	Spring Force N (kgf)
65	70	00	38	19.6 (2.0)	39.2 (4.0)	667 (69.1)
100	100	00	40	29.4 (3.0)	58.8 (6.0)	1111 (113.4)
150	100	00	40	58.8 (6.0)	88.2 (9.0)	2051 (209.3)
200	110	00	40	78.4 (8.0)	117.6 (12.0)	2733 (278.9)

## **■**Coil Spring Specifications


Moun	t face			Working For	ce [kN (tonf)]		
w	н	Working Angle	Travel	Standard Working Force 1,000,000 strokes	Allowable Working Force 300,000 strokes		
			25				
52	65	00	40	14.7 ( 1.5)	29.4 ( 3.0)		
			60				
		00	40				
		00	60				
		05	45				
		05	70				
65	70	10	45	19.6 ( 2.0)	39.2 ( 4.0)		
03	70	10	70	19.0 ( 2.0)	39.2 ( 4.0)		
		15	45				
		15	70				
		20	45				
		20	70				
			40				
	100	00	60	29.4 ( 3.0)	58.8 ( 6.0)		
			80				
		05	45				
			70				
100	100	10	45				
	90		70	39.2 ( 4.0)	78.4 ( 8.0)		
		15	45	,	( ,		
			70				
		20	45				
			70				
		00	40	58.8 ( 6.0)	88.2 ( 9.0)		
			60				
		05	45				
			70				
150	100	10	45				
			70	64.7 ( 6.6)	98.0 (10.0)		
		15	45	` ,	, ,		
			70				
		20	45				
			70				
200	110	00	40	78.4 ( 8.0)	117.6 (12.0)		
			60				
250		00	40	98.0 (10.0)	147.0 (15.0)		
	130		60				
300		00	40	117.6 (12.0)	176.4 (18.0)		
			60		(.0.0)		

SKCA


# **SKCA** [Overview]

## **Product Information**

#### ■SKCA52, 65 Assembly Instructions



#### ■SKCA100, 150 Assembly Instructions




Copyright © Sankyo Oilless Industry, Inc. All Rights Reserved.


#### Disassembly

- 1) Remove Hexagon Socket Head Bolts (a), to pull out Stopper Plate (5).
- 2) Pull out and remove Cam Slider (1) from Cam Holder (3) to the rear.

## ■SKCA200, 250 Assembly Instructions



#### ■SKCA300 Assembly Instructions



#### Assembly

Assembly is the reverse procedure of disassembly.

- Ensure that all parts are clean, particularly the sliding components to which a small amount of lubricant is applied and is then placed in position.
- Take care that the respective tolerances are observed when assembling Cam Slider and Cam Holder, which also should be identified by the same serial number.
- · Make sure that all bolts are tighten to the recommended torque after assembly and disassembly.




956

sure that an botto are lighten to the recommended torque after assembly and disassembly.

## **SKCA** [Overview]

#### **Product Information**

#### ■SKCA65, 100, 150 Assembly Instructions (Gas Spring)



#### Disassembly

- 1) Remove Hexagon Socket Head Bolts (a), to pull out Stopper Plate (5).
- 2) Pull out and remove Cam Slider (1) from Cam Holder (3) to the rear.

#### Assembly


Assembly is the reverse procedure of disassembly.

- Ensure that all parts are clean, particularly the sliding components to which a small amount of lubricant is applied and is then placed in position.
- Take care that the respective tolerances are observed when assembling Cam Slider and Cam Holder, which also should be identified by the same serial number.
- · Make sure that all bolts are tighten to the recommended torque after assembly and disassembly.

## ⚠ Gas Spring

Please contact your local sales representative if you prefer to use a gas spring not specified in our catalog. For use and maintenance of gas spring, please contact the manufacturer directly.

#### ■SKCA200 Assembly Instructions (Gas Spring)



#### Disassembly

- 1) Remove Hexagon Socket Head Bolts (a), to pull out Stopper Plate (5).
- 2) Pull out and remove Cam Slider (1) from Cam Holder (3) to the rear.

#### Assembly

Assembly is the reverse procedure of disassembly.

- Ensure that all parts are clean, particularly the sliding components to which a small amount of lubricant is applied and is then placed in position.
- Take care that the respective tolerances are observed when assembling Cam Slider and Cam Holder, which also should be identified by the same serial number.
- · Make sure that all bolts are tighten to the recommended torque after assembly and disassembly.


## 


Please contact your local sales representative if you prefer to use a gas spring not specified in our catalog. For use and maintenance of gas spring, please contact the manufacturer directly.


SKCA


958

#### SKCA100-00-40









	'	2-∮13 H7	'
	6.3	190	-1
12.5	105±0.05	<del></del>	ان
6.3/	45	4	17.5
1 + +		<b>6</b> ————————————————————————————————————	<del>}</del>
	Clearance 1		
175 160 150		,,	140±0.02
5 5			1 4
<del>  <u>+ +</u></del>	₩	•	<del> </del>
	16 45	130	4-\psi 14-\psi 20
	16 45	130	4-\$\phi_14-\$\phi_20

Working Fore	Allowable	909	Force (gf)	Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel	Spring Type PS	
Working Force 1,000,000 strokes	Working Force 300,000 strokes	Initial Load	Final Load	kg	kg						
29.4	58.8	188.0 (19.2)	1130.9 (115.2)	40.5	27.0	CKCA	100			No Code (Coil Spring) NISO	
(3.0)	(6.0)	_	1111 (113.4)	10.5	37.0	SKCA	100	00	40	GK NGK GD NGD GS NGS	

No Code: Coil Spring GK: Gas Spring (KALLER) GD: Gas Spring (DADCO) GS: Gas Spring (SDT) NGK/NGD/NGS: Without Gas Spring NISO: Without Coil Spring Parts for spring assembly are included.



Catalog No.	W	]-	θ	]-	S	]-	PS	- Option
SKCA	100	_	00	_	40	_	GK	– NF



Option Code	Specification					
NF	Nitrogen gas not charged.					
N12	$\phi$ 12 mm dowel holes provided on holder.					

Refer to page 377 for the machining details of tapped holes and dowel holes for retainer mounting.

#### ■Spring Specification


No.	PS	Spring Model	Qty	Remark
	No Code	TF27-100	2	Coil Spring 11.78 N/mm (1.20 kgf/mm)
8	GK	R19-50-Yellow	1	Gas Spring (KALLER)
0	GD	C.090.050.YW	1	Gas Spring (DADCO)
	GS	SFL.90.50	1	Gas Spring (SDT)

Gas filling pressure: 18 MPa


Life expectancy of Coil Spring is approximately 300,000 strokes.

#### **■**Spring Diagram

· Spring Model TF27-100 (2 pieces)




#### ■Rear Removal Space





SKCA 100


990

Refer to page 1011, 1012 for Table of Components.









Working Fore	ce [kN (tonf)] Allowable Working Force	opg	Spring Force N (kgf)			Catalog No.	w	θ	Travel
1,000,000 strokes		Initial Load	Final Load	kg	kg				
29.4	58.8	204.1	1146.1	10.5	38.0	SKCA	100	00	60
(3.0)	(6.0)	(20.8)	(116.8)	10.5	30.0	SKCA	100	00	00




Catalog No.	W	] —	θ	-	S
SKCA	100	_	00	_	60




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.


### **■**Spring Diagram


- · Spring Model TF27-150 (2 pieces)
- · Spring constant 7.85 N/mm (0.80 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.





#### Rear Removal Space











100 (W)

	2-	<u>Ψ13 H7</u>
m  -	220	
135±0	.05	101
	1/	17.5
<b>**</b>	<b>ø</b> —	
H	·	
Clearance 1		
		140±0.02
		140
H		
<b>├</b>	�—	<del></del> +
¥		- 3
15 45	160	4-\$\phi_14-\$\phi_20
	Clearance 1	220 135±0.05  Clearance 1

Standard	Working Force [kN (tonf)]  Standard Allowable Working Force Working Force		Spring Force N (kgf)		Total Weight	Catalog No.	w	θ	Travel
1,000,000 strokes		Initial Load Final Load		kg	kg				
29.4	58.8	169.9	1302.7	11.9	44.0	SKCA	100	00	80
(3.0)	(6.0)	(17.3)	(132.5)	11.9	44.0	SKCA	100	UU	00



Catalog No.	W	]-	θ	-	S
SKCA	100	_	00	_	80




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.

Refer to page 377 for the machining details of tapped holes and dowel holes for retainer mounting.


#### **■**Spring Diagram


- · Spring Model TF30-200 (2 pieces)
- · Spring constant 7.08 N/mm (0.72 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.





## Rear Removal Space











Working For	Working Force [kN (tonf)]		72 Opring 1 0100		Total				
Standard	Allowable	N (I	N (kgf)		Weight	Catalog No.	W	θ	Travel
Working Force 1,000,000 strokes	Working Force 300,000 strokes	Initial Load	Final Load	kg kg					
39.2	78.4	263.8	1111.6	7.2	33.0	SKCA	100	05	45
(4.0)	(8.0)	(26.9)	(113.3)	1.2	33.0	SKCA	100	05	45




Catalog No.	W	] —	θ	-	S
SKCA	100	_	05	_	45




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.

#### **■**Spring Diagram


- · Spring Model TF27-125 (2 pieces)
- · Spring constant 9.42 N/mm (0.96 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## ■Rear Removal Space














Working Fore	ce [kN (tonf)] Allowable Working Force	Spring Force N (kgf)		Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel S
1,000,000 strokes		Initial Load	Final Load	kg	kg				
39.2	78.4	195.2	1137.4	10.0	38.0	SKCA	100	OF	70
(4.0)	(8.0)	(20.0)	(116.6)	10.0	30.0	SKCA	100	US	70




Catalog No.	W	]-	θ	-	S
SKCA	100	_	05	_	70




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.

### **■**Spring Diagram


- · Spring Model TF27-175 (2 pieces)
- · Spring constant 6.73 N/mm (0.69 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## ■Rear Removal Space











175	165	150	89	90	1 0±0.05	60	<b>(</b>	140+0.92	-
	, _			5_40	<u>)</u> ;	105			<b>1</b> 4-∮20

Working Fore	ce [kN (tonf)] Allowable Working Force	opg	Force (gf)	Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel S
1,000,000 strokes		Initial Load	Final Load	kg	kg				
39.2	78.4	263.8	1111.6	7.0	33.0	SKCA	100	10	45
(4.0)	(8.0)	(26.9)	(113.3)	7.0	33.0	SKCA	100	10	45




Catalog No.	W	]-	θ	-	S
SKCA	100	_	10	_	45




Option Code	Specification
N12	∮12 mm dowel holes provided on holder.

#### **■**Spring Diagram

- · Spring Model TF27-125 (2 pieces)
- · Spring constant 9.42 N/mm (0.96 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## Rear Removal Space





SKCA 100


1000

Refer to page 1011 for Table of Components.









Working Fore	ce [kN (tonf)] Allowable Working Force	opg	Force (gf)	Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel
1,000,000 strokes		Initial Load	Final Load	kg	kg				
39.2	78.4	195.2	1137.4	10.0	38.0	SKCA	100	10	70
(4.0)	(8.0)	(20.0)	(116.6)	10.0	30.0	SKCA	100	10	10

	-							
- 1			1					
		_	٠,					
	Order							


Catalog No.	W	]-	θ	-	S
SKCA	100	_	10	_	70




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.


#### **■**Spring Diagram


- · Spring Model TF27-175 (2 pieces)
- · Spring constant 6.73 N/mm (0.69 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.





## Rear Removal Space











		10	ć	90	±0.05	60	2- <b>∮</b> 13	H7_	
6.	3/	12.5				7	/		17.5
1	7	1		1	<b>)</b> +	<b>&amp;</b> -	<b>(</b>		
175	165	150		Cleara	ance 1				140±0.02
	, ,	_			<b>)</b> +	<b>&amp;</b> -	•		
_				15 40		105		4-	φ14-φ20

	/	<b>\</b>	\				
1		F	45°				
	55.1		/	1			
7	_		15°				
7			~	-			

Working For	ce [kN (tonf)]	Spring	Force	Cam Slider	Total				Travel S
Standard	Allowable	N (I	kgf)	Weight	Weight	Catalog No.	W θ	θ	
Working Force 1,000,000 strokes	Working Force 300,000 strokes	Initial Load	Final Load	kg	kg				
39.2	78.4	263.8	1111.6	7.0	33.0	SKCA	100	15	45
(4.0)	(8.0)	(26.9)	(113.3)	7.0	33.0	SRCA	100	15	45




Catalog No.	W	]-	θ	-	S
SKCA	100	_	15	_	45




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.


### ■Spring Diagram


- · Spring Model TF27-125 (2 pieces)
- Spring constant 9.42 N/mm (0.96 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## ■Rear Removal Space







6.3/	Tray	2 el 88 4.6 89
200		4.6 8 100 (W)
171.5	1	130.17
6.3	216.48	9
	243.48	120
	190	20



Working Fore	ce [kN (tonf)] Allowable Working Force	Opinig	Force (gf)	Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel S
1,000,000 strokes		Initial Load	Final Load	kg	kg				
39.2	78.4	195.2	1137.4	10.0	38.0	SKCA	100	15	70
(4.0)	(8.0)	(20.0)	(116.6)	10.0	30.0	SKCA	100	13	70




Catalog No.	W	] —	θ	-	S
SKCA	100	_	15	_	70




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.

### ■Spring Diagram


- · Spring Model TF27-175 (2 pieces)
- · Spring constant 6.73 N/mm (0.69 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## ■Rear Removal Space








Cam Diagram





100 (W)

	6.3		160	-	
12.5	90	90±0.05		2-∮13 H7	
6.3/					17.5
ŤŦ		—÷(̇̀́́)÷	<b>A</b>	<del>(A)</del>	
1	41	·\ <del>\\'</del>	•		_
		Clearance 1	1		
.0 10			-		0.02
175 165 150					140±0.02
	Н				
1		— <del>(A)</del>	<b>�</b> -	<del>(1)</del>	<u> </u>
1 -		<u> </u>			
	15	40	105	`	4-\$\psi 14-\$\psi 20

Working Force [kN (tonf)]		Spring Force		Cam Slider	Total				
Standard	Allowable Working Force	N. (1 (5)		Weight	Weight	Catalog No.	W	θ	Travel S
Working Force 1,000,000 strokes		Initial Load	Final Load	kg	kg				
39.2	78.4	263.8	1111.6	7.0	32.0	SKCA	100	20	45
(4.0)	(8.0)	(26.9)	(113.3)	7.0	32.0	SKCA	100	20	45



Catalog No.	W	]-	θ	-	S
SKCA	100	_	20	_	45




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.


Refer to page 377 for the machining details of tapped holes and dowel holes for retainer mounting.

#### **■**Spring Diagram

- · Spring Model TF27-125 (2 pieces)
- · Spring constant 9.42 N/mm (0.96 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.




## ■Rear Removal Space



Standard Cam Units

SKCA 100



Working Force [kN (tonf)]  Standard Allowable		Spring Force N (kgf)		Cam Slider Weight	Total Weight	Catalog No.	w	θ	Travel S
Working Force 1,000,000 strokes	Working Force 300,000 strokes	Initial Load	Final Load	kg	kg				
39.2	78.4	195.2	1137.4	10.0	39.0	SKCA	100	20	70
(4.0)	(8.0)	(20.0)	(116.6)	10.0	39.0	SKCA	100	20	70




Catalog No.	W	]-	θ	-	S
SKCA	100	_	20	_	70




Option Code	Specification
N12	$\phi$ 12 mm dowel holes provided on holder.

#### **■**Spring Diagram

- · Spring Model TF27-175 (2 pieces)
- · Spring constant 6.73 N/mm (0.69 kgf/mm)
- · Life expectancy of Coil Spring is approximately 300,000 strokes.



## ■Rear Removal Space



# SKCA 100

1009

Clearance 1


130

4-\$\phi\$14-\$\phi\$20

# **SKCA** [Table of Components]


## **Die Mounted Cam Unit**





No.	Description	Qty	Material and Remark
1	Cam Slider	1	Cast Iron with Graphite
2	Cam Driver	1	Cast Iron with Graphite
3	Cam Holder	1	Cast Iron
4	Upper Plate	2	Copper Powder Sintered
5	Stopper Plate	1	Steel
6	Positive Return Follower	1	Steel
7	Spring Guide Pin	2	<i>∮</i> 12x40
8	Coil Spring	2	TF27-100 40st
8	Coil Spring	2	TF27-125 45st
8	Coil Spring	2	TF27-150 60st
8	Coil Spring	2	TF27-175 70st
8	Coil Spring	2	TF30-200 80st

SKCA100 (Gas Spring)



No.	Description	Qty	Material and Remark
1	Cam Slider	1	Cast Iron with Graphite
2	Cam Driver	1	Cast Iron with Graphite
3	Cam Holder	1	Cast Iron
4	Upper Plate	2	Copper Powder Sintered
5	Stopper Plate	1	Steel
6	Positive Return Follower	1	Steel
8	Spring	_	Refer to the Spring Specification.
11	Stop Pin	1	Gas Spring specification only

Bolts, nuts, dowels, and washers for assembly are not indicated.

SKCA 100

1012

Bolts, nuts, dowels, and washers for assembly are not indicated.

## **Cam Units [Overview]**

#### **Information**

#### ■ Tapped Hole and Dowel Hole (Prepared Hole, Finish) Machining for Retainer Mounting

#### Instruction method for machining

Indicate the tapped hole diameter and the dowel hole (or prepared hole) diameter with the XY coordinates.


#### To indicate the coordinates


- The origin is positioned at the upper left corner of the mount face. (However, machining uses our machining datum as the reference.)
- · Indication symbol
- -M···Tapped hole, -N···Dowel prepared hole, -K···Dowel finish hole

#### **Machining standard**


- · Tapped holes and dowel prepared holes are machined to general tolerances.
- The hole depth is 2.5 times the diameter for both tapped holes and dowel holes. The dowel pilot hole is processed for 2 times the diameter.
- $\cdot$  The dowel hole spacing is machined to the tolerance of  $\pm 0.02$ . The hole tolerance is H7.


#### (Example of Aerial Cam Unit)





#### ⟨Example of Die Mounted Cam Unit⟩





### **■**Other machining

Please give instructions on a separate drawing for drilling or cutting other than tapped holes and dowel holes.